


Ersatzteile zu Messing Plattenschieber Art. 0080



Best.Nr.	Artikel	
2228	Körper, 4"	(Pos. 1)
2337	Körper, 6"	(Pos. 1)
2215	Körper, 8"	(Pos. 1)
2217	Dichtung, 4"	(Pos. 2)
2338	Dichtung, 6"	(Pos. 2)
2250	Dichtung, 8"	(Pos. 2)
2255	Dichtring, 4" OR 4400	(Pos. 3)
2326	Dichtring, 6" OR 4587	(Pos. 3)
2254	Dichtring, 8" OR Ø200x5	(Pos. 3)
2244	Dichtring, 4" OR 4462	(Pos. 4)
2185	Dichtring, 6" OR 4650	(Pos. 4)
2254	Dichtring, 8" OR Ø200x5	(Pos. 4)
2251	Muffe, 4", inkl. Pos. 2, 3, 4	(Pos. 5)
2339	Muffe, 6", inkl. Pos. 2, 3, 4	(Pos. 5)
2252	Muffe, 8", inkl. Pos. 2, 3, 4	(Pos. 5)
2043	Dichtring, 4" OR 207	(Pos. 6)
2253	Dichtring, 6" OR 232	(Pos. 6)
2234	Dichtring, 8" OR 244	(Pos. 6)
2257	Schieberplatte, 4	(Pos. 7)
2358	Schieberplatte, 6"	(Pos. 7)
2258	Schieberplatte, 8"	(Pos. 7)
2342	Klemme, 4" + 6" zu Schraube	(Pos. 8)
2271	Klemme, 8" zu Schraube	(Pos. 8)
2341	Schraube M 6x20, 4" - 6"	(Pos. 9)
2259	Schraube M 8x30, 8"	(Pos. 9)
2282	Flanschdichtung, 4"	(Pos. 10)
2345	Flanschdichtung, 6"	(Pos. 10)
2315	Flanschdichtung, 8"	(Pos. 10)
2044	Gestänge lose, 4"	(Pos. 11)
2313	Gestänge lose, 6"	(Pos. 11)
2219	Gestänge lose, 8"	(Pos. 11)
2870	Schieber-Oberteil, 4"	(Pos. 12)
2273	Schieber-Oberteil, 6"	(Pos. 12)
2871	Schieber-Oberteil, 8"	(Pos. 12)
2068	Stopfbuchse 27x20x8, 4"+6"	(Pos. 13)
2851	Stopfbuchse 32x22x8, 8"	(Pos. 13)
2183	Stopfbuchsenmutter M30x2, 4" - 6"	(Pos. 14)
2850	Stopfbuchsenmutter M35x2, 8"	(Pos. 14)

Ersatzteile zu Messing Plattenschieber Art. 0080

Best.Nr.	Artikel	
2110	Gabel	(Pos. 15)
1769	Schraube TCEI M8 x 16	(Pos. 16)
2343	selbstsichernde Mutter M6	(Pos. 17)
2874	selbstsichernde Mutter M8	(Pos. 17)